737-800 Normal Checklist

PRELIMINARY PREFLIGHT

Required Charts (DEP / ARR / ALTN)	ON BOARD
Flight Briefing Package / Weather Charts	ON BOARD
Parking Brake	ON
Engine Start Levelers	CUT OFF
Landing Gear Lever	DOWN
Battery	ON
Standby Power	ON
Bus Transfer	AUTO
Navigation IRS	START CALIBRATION
FSFK started and connected	CHECKED

PREFLIGHT

APU / Ground Power	STARTED / CONNECTED
Light Test / Fire Panel Test	CHECKED
Navigation, IRS & Displays	CALIBRATED & CHECKED
Galley Power	ON
Emergency Exit Lights	ARMED
Window Heat	ON
Engine Hydraulics	ON
Hydraulic Oil QTY / Engine Oil QTY	CHECKED
Passenger Oxygen	CHECKED & NORMAL
Air Condition	2 PACKS, BLEED ON
Pressurization Isolation Switch	AUTO
Autopilots	DISENGAGED
Flaps	UP, NO LIGHT
Spoiler	DOWN
Pitot heat	TEST & OFF
Anti-Ice	TEST & OFF
Flight Controls & Spoilers	ON
Flight Director	ON
Instruments	CROSS CHECKED
Clock	SET ON
CDU preflight	SET
Boarding	COMPLETED
Take Off Briefing	REVIEWED

BEFORE START

Doors	CLOSED & ARMED
Fuel Pumps and Quantity	ON & CHECKED
Cross Feed	TESTED & CLOSED
МСР	V2+20 / HDG / ALT
Takeoff speeds	SET & CHECKED
Trim	SET & CHECKED
Take Off Briefing	COMPLETED
Pressurization	SET CRUISING ALTITUDE
Passenger Signs	ON
Electric Hydraulic Pumps	ON
Anti Collision Light	ON
Cockpit Door	LOCKED

ENGINE START	
Engine Ignition	L / BOTH / R
Left and Right Pack	OFF
L Start Switch	ON
L FF (Fuel Flow) / N1 increase / Oil pressure / ENG stable	СНЕСК
R Start Switch	ON
R FF (Fuel Flow) / N1 increase / Oil pressure / ENG stable	СНЕСК

AFTER START	
Electrical Generators	ON
Engine Bleed Left and Right	ON
APU Bleed Switch	OFF
Left and Right Pack	AUTO / HIGH
Trim Air & Recirc Fans	ON / AUTO
Yaw Dumper	ON
Ground Equipment	REMOVED
Flight Controls	TESTED
Flaps	SET & GREEN LIGHT
Taxi Lights	ON

BEFORE TAXI	
Probe Heat	ON
Anti-Ice	AS REQUIRED
Pressurization Isolation Switch	AUTO
Engine Start Switches	CONT
Auto Brake	RTO
Engine Start Levelers	IDLE & LOCKED
Master Caution	CHECKED & RESET

BEFORE TAKEOFF	
Flaps	SET & GREEN LIGHT
APU	OFF
Left and Right Pack	AS REQUIRED
Master Caution	CHECKED & OFF
Secured Cabin Report	RECEIVED
Taxi Lights	OFF
Strobe Lights	ON
Landing Lights	ON
Transponder	TA/RA

AFTER TAKE OFF / CLIMB	
Left and Right Pack	AUTO / HIGH
Pressurization	CHECKED CRUISE ALT.
Engine Start Switches	OFF
Flaps	UP & NO LIGHT
Landing Gear	UP & OFF
Auto Brake	OFF

737-800	Normal	Checklist
---------	--------	-----------

AT 10.000 FEET	
Landing Lights	OFF
Seatbelts	AS REQUIRED

DESCEN	т
Anti-Ice	AS REQUIRED
Pressurization	SET LANDING ALTITUDE
Master Caution	CHECKED
Landing Performance	CALCULATED
IAS Bug	CHECKED & SET
Auto Brake	SET
Approach Briefing	COMPLETED
Seatbelts	AS REQUIRED

AT 10.000 Feet	
Landing Lights	ON
Seatbelts	ON

APPROACH	
Altimeter	SET & CROSS CHECKED

LANDING		
Engine Start Switches	FLIGHT	
Master Caution	CHECKED & OFF	
Spoiler	ARMED & GREEN LIGHT	
Landing Gear	DOWN & 3 GREENS	
Flaps	SET & GREEN LIGHT	
Missed Approach Altitude	SET	

GO AROUND		
Thrust Levers	MAX	
Autopilot	DISCONNECTED	
Rotate the aircraft to 10°		
With positive rate of climb		
Flaps	5°	
Landing Gear	UP	
Minimum Airspeed	V2	
At the level-off height proceed as in normal takeoff		

AFTER LANDING		
Transponder	STANDBY	
Weather & Terrain Radar	OFF	
Spoiler	DOWN	
Flaps	UP & NO LIGHT	
Auto Brake	OFF	
Landing Lights	OFF	
Strobe Lights	OFF	
Taxi Lights	ON	
APU	STARTED	
Engine Start Switches	OFF	
Probe Heat Switches	OFF	
APU Generator Switches	ON	
Flight Director	OFF	

ENGINE SHUTDOWN			
APU	RUNNING & CONNECTED		
Parking Brake	SET		
Thrust Levers	IDLE		
Internal and external Lights	AS REQUIRED		
APU Bleed	ON		
Engine Bleed Left and Right	OFF		
Engine Start Levelers	CUT OFF		

PARKING		
Ground Power	CONNECTED	
Seatbelts	OFF	
Window Heat	OFF	
Taxi Lights	OFF	
Anti-Ice	OFF	
Electric Hydraulic Pumps	OFF	
Yaw Dumper	OFF	
Fuel Pumps	OFF	
Anti Collision Light	OFF	
Doors	DISARMED & OPENED	

TERMINATION FLIGHTS ONLY		
Galley Power	OFF	
Engine Hydraulics	OFF	
Trim Air & Recirc Fans	OFF	
APU Bleed	OFF	
Emergency Exit Lights	OFF	
Left and Right Pack	OFF	
Pressurization Isolation Switch	CLOSED	
IRS Left & right	OFF	
APU / Ground Power	OFF / DISCONNECTED	
Bus Transfer	OFF	
Standby Power	OFF	
Battery Switch	OFF	